

## JYB20 Concise Manual

Thank you for purchasing our company's JYB20 (Beidou bulldozer leveling guidance system). Please read this manual carefully before working, so that you can use this product quickly, correctly and safely.

**Disclaimer:**

This document does not convey, by implication, estoppel, or otherwise, any right or license under or under patents, trademarks, copyrights or titles of the Company or any third party.

**The company is not responsible for any changes or deletions of relevant work data caused by your use or inability to use this product.**

**Notice to users:**

The display terminal is mounted at a convenient location for the driver using a RAM bracket. For tractors without a cab, the instrument should be protected from sun exposure/rain, and care must be taken to prevent the instrument from falling to the ground or being strongly impacted by other objects.

- The power must be cut off before installing and disassembling each cable;
- Do not use hard objects when operating the display screen;
- Please connect your device strictly according to the requirements in this manual;

When supplying power, pay attention to the equipment power supply requirements (DC12V);

- Pay attention to take appropriate lightning protection measures to prevent lightning strikes;


The equipment is damaged due to force measure (lightning strike, high voltage, collision, etc.), which is not within the scope of free maintenance of the company;

- It is forbidden to disassemble the product by yourself, otherwise the warranty will not be granted;
- When using this system, it should be in an open field far away from the shelter;
- Please stay away from interference sources such as strong electric fields, magnetic fields, high-voltage lines, and radio signal towers during use of the device.

**List of main instruments:**


name	Terminal	GNSS antenna	Camera	Power cable	Main cable	GNSS cable	Camera adapter cable	RAM bracket	4G Antenna	R26 base
PCS	1	2	1	1	1	2	1	1	1	1
Remark	Radio module included									

## System connection diagram:



- ①: Display terminal: fixed at the convenient operation position of the cab;
- ②: GNSS cable: connect the display terminal to the GNSS antenna;
- ③: 4G antenna: connected to the display terminal;
- ④: GNSS antenna: connected to the display terminal through the antenna cable, fixed at a suitable position on the left side of the shovel body;
- ⑤: GNSS antenna: connected to the display terminal through the antenna cable, fixed at a suitable position on the right side of the shovel body;
- ⑥: Communication main cable: connect the display terminal and other interfaces;
- ⑦ : Camera extension cable, connecting the display terminal and the camera;
- ⑧ : On-board camera, real-time monitoring of shovel status
- ⑨ : Power cord: directly connected to the 12V battery, pay attention to the positive and negative poles to prevent reverse connection;

## Job display information:



## Job operation process:

1. Set up a mobile base station (the network base station ignores this step);
2. Check whether the instrument is firmly fixed;
3. Check whether the cable is connected correctly;
4. Set the working datum:
  - a. Start the bulldozer;
  - b. Turn on the system power switch and start the level ground guidance software;
  - c. Click "SYSTEM" to select a suitable base station;
  - d. Select "TASK" - "New" to create job information; e. Click "MODE" and select "LEVEL/SLOPE" mode;
5. After setting the leveling mode, click "AUTO" to start the operation;
6. Drive the bulldozer for guided leveling work.

Latest software download link:

<https://www.dropbox.com/sh/shv8twous76ja51/AACMkxQJwI8yOZGB1GUkewEPa?dl=0>

### Common situation:

1. **The bulldozing shovel cannot continue to push the soil** during leveling: click the "SET H" - " ↓ " icon to set the base level down by 3~5cm;
2. During leveling, **the bulldozing blade continues to push the soil without unloading**: click the "SET H" - " ↑ " icon, and set the base level to adjust by 3~5cm;
3. **Occasionally, the bulldozer blade pushes too much soil** during leveling: in automatic state, manually control the lifting of the bulldozer blade;
4. Re-adjust the datum level during leveling: adjust the height of the bulldozer blade, click "SET H" - "BASE" - "CONFIRM";

### Common exceptions:


1. There is no response when the system power switch is turned on: Check the power cord, insurance, and battery power;
2. The base station signal is abnormal: click "SIGNAL" - "CORS" - Log in to the CORS account again

### Equipment main parameters:

Name: Beidou satellite grader
Signal tracking number: Beidou, GPS, GLONASS
RTK Accuracy: $\pm (20+1 \times 10^{-6} \times D)$ mm
Base station selection: network/radio station/CORS
Protection level: IP67 dustproof and waterproof (display terminal)
Display indication: 10-inch touch screen
Working temperature: $-20^{\circ}\text{C} \sim +65^{\circ}\text{C}$
Working voltage: DC12V
Tablet size: 281mm $\times$ 181mm $\times$ 42mm
Weight: about 4Kg (system)

## 1. Base station selection:

- First check the RTK status, if it is displayed as "single", then select the base station;
- SIGNAL -- CORS -- Log in to your CORS account.



- After connecting to the base station, check whether the RTK status is "Fixed", and the reference display is a digital non-text prompt;


## 2. New job information:

TASK -- NEW -- CREATE ; (or click "CREATE" directly after starting the software)



### 3. Set base height (horizontal mode):

a. Manually adjust the bulldozing blade to a position 5~10cm away from the ground;



b. MODE -- LEVEL -- H Lock -- SURE




c. MODE -- LEVEL -- H System -- SURE




#### 4. Slope mode (Two-point mode -- Heading mode -- Double mode)




a. MODE -- SLOPE -- Two-point mode -- Collect point A -- Collect point B -- FINISH -- AUTO



b. MODE -- SLOPE -- Heading mode -- Collect point A -- Collect point B -- FINISH -- AUTO




c. MODE -- SLOPE -- Double mode -- Collect point A -- Collect point B -- Collect point c -- FINISH -- AUTO





**7. Driving status(SYSTEM--Other--Tick"display driving status"),real-time display of driving status.**



**8. Localization map (After the job is completed, start the software again to load the last job track).**

**9. ALL display track (After the job is completed, start the software again to load the last job track)**

